MANITOWOC ICE
2110 SOUTH 26TH STREET, MANITOWOC, WI 54220
800-545-5720
WWW.MANITOWOCICE.COM

Instruction Sheet

Subject: RNS0600 & RNS1000 Lower Roller Bearing

REPLACEMENT BEARING INSTALLATION

⚠Warning

Authorized Service Representatives are obligated to follow industry standard safety procedures, including, but not limited to, local/national regulations for disconnection / lock out / tag out procedures for all utilities including electric, gas, water and steam.

⚠DANGER

Disconnect electric power to the ice machine at the electric switch box before proceeding. Failure to disconnect the power at the main power supply disconnect could result in serious injury or death. The power switch DOES NOT disconnect all incoming power.

The existing bearing and spacer are replaced with 3 spacers and a roller bearing.

Step 1 Disconnect power to the ice machine.

Step 1 Disassemble evaporator and discard the existing bearing and spacer.

Step 2 Install the replacement roller bearing and spacers in the evaporator in the order shown in the photo.

Step 3 Reassemble evaporator, restore power and test run.





Document Number: 000013984 Rev00 6/16