MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

MANITOWOC #76-2396-3
INSTALLATION INSTRUCTIONS FOR
UNITIZED SENSOR ASSY-50HZ

1. IF PLASTIC MOUNTING TRACK IS USED WITH EXISTING BOARD, REPLACE WITH METAL BRACKET.
2. DISREGARD METAL MOUNTING BRACKET AND SCREWS IF ICE SENSOR IS MOUNTED DIRECTLY TO BACK WALL.

0862

SYM	DESCRIPTION OF REVISIONS	E.C.O.	BY	APP	DATE

TOLERANCE UNLESS SPECIFIED
.00=±.03, .000=±.015, ANG=±1
DO NOT SCALE THIS DRAWING

ITEM NO.	NO. REQD	DESCRIPTION	MATERIAL	PART NO.
1	–	INSTALLATION INSTRUCTIONS	PAPER	8008623

THIS PRINT REMAINS THE PROPERTY OF MANITOWOC EQUIPMENT WORKS ALL INFORMATION CONTAINED THEREON IS CONFIDENTIAL. IT IS LOANED, SUBJECT TO RETURN UPON DEMAND, AND ON EXPRESS CONDITION THAT IT IS NOT TO BE COPIED OR USED DIRECTLY OR INDIRECTLY IN ANY WAY WHATSOEVER DETRIMENTAL TO OUR INTERESTS.

MANITOWOC EQUIPMENT WORKS
MANITOWOC, WISCONSIN

TITLE: INSTALLATION INSTRUCTIONS

DR	APP	E.C.O.	SIZE	DWG NO.	SHEET
KDV	LM	3274	B	800862	1 OF 1

SCALE: 1.00 = 1.00 DATE: 10/03/90