DANFOSS SOLENOID VALVE/SHIELD ASSEMBLY

Installation Instructions

Warning!
Disconnect electrical power before performing this procedure.

1. Remove existing solenoid valve from unit.
2. Replace with new valve/shield assembly and braze using included special brazing instructions.
    a. If you are replacing an Alco valve, remove the shield from the assembly and install new valve.
    b. If you are replacing a Danfoss valve, remove existing valve and install new valve/shield assembly.

Manitowoc Ice, Inc.
2110 South 26th Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879
Web Site - www.manitowocice.com
8015383
03/11/04