MANITOWOC ICE
2110 SOUTH 26TH STREET, MANITOWOC, WI 54220

800-545-5720
WWW.MANITOWOCICE.COM

Service Bulletin

Subject: Safely Disconnecting the BLE Module

INDIGO NXT MODELS WITH BLE MODULE

Disconnecting the BLE module in applications where Bluetooth functionality is prohibited, such as government facilities, correctional institutions, military installations, and other high-security environments.

⚠Warning

Authorized Service Representatives are obligated to follow industry standard safety procedures, including, but not limited to, local/national regulations for disconnection / lock out / tag out procedures for all utilities including electric, gas, water and steam.

1. Disconnect power to the ice machine.
2. Remove the front panel, top cover, right side panel and the control box cover.
3. Disconnect the BLE module cable from the J19 connector on the control board.
4. Remove the BLE module, cable and bracket from the ice machine. Discard all BLE components.
5. Reinstall control box cover, right side panel and top cover. Secure the front panel.
6. Restore power to the ice machine.
7. Turn the ice machine on and verify operation.

NOTE: Do not install BLE module on any other ice machine. BLE modules must be factory installed.

