IB SERIES ICE MACHINES HEAD
115/60/1, 230/50/1 AND 208-230/60/1

CAUTION: DISCONNECT POWER BEFORE WORKING ON ELECTRICAL CIRCUITRY.

SEE SERIAL PLATE FOR VOLTAGE

