S ICE MACHINES
SELF CONTAINED 460/60/3 PHASE

SEE SERIAL PLATE FOR VOLTAGE

CAUTION: DISCONNECT POWER BEFORE
WORKING ON ELECTRICAL CIRCUITY

