K00317001
BUN PAN KIT
ONE-DOOR

1. REMOVE SHELVES.

2. REMOVE FOUR PILASTERS FROM MOUNTING STUDS IN CABINET.

3. INSTALL THE SHORT PILASTERS FROM KIT ON THE TOP OR BOTTOM HALF OF THE CABINET. THIS ALLOWS THE SHELVES TO BE REINSTALLED IN THIS HALF OF THE CABINET.

4. POSITION BRACKETS OVER THE MOUNTING STUDS IN THE CABINET (REFER TO FIGURE 1 FOR INSTALLATION).

5. SNAP WIRE CLIPS IN GROOVE OF THE MOUNTING STUDS IN THE CABINET.

6. LOCATE THE BUN PAN RACKS OVER THE MOUNTING STUDS ON THE BRACKETS.

7. SNAP WIRE CLIPS IN GROOVE OF BRACKETS TO SECURE THE BUN RACKS.

8. INSTALL THE BUN PANS.