7625993 - CYCOLAC CHIPS WITH INSTRUCTIONS

Cycolac Chips and Instructions for Making Liquid Cycolac

Mix with acetone. Makes 6 ounces. Preparation time is approximately two hours.

Cycolac is used to mend cracks, seal gaps, etc. on sump troughs and dispenser door liners. **Do not use on other plastic parts.**

Materials Needed

1 package Cycolac chips
1 1/2 cups acetone (available at hardware stores)
1 clean glass or metal container (2 qt.)
1 wood or metal spoon or similar type mixing device
rubber gloves
safety goggles

NOTE: Acetone is a hazardous chemical. Wear safety goggles and rubber gloves when mixing ingredients. Follow label instructions.

Instructions for Mixing Cycolac

Step 1
- Pour Cycolac chips from package into container.

Step 2
- Add 1 1/2 cups of acetone and mix thoroughly for ten minutes.

Step 3
- Stir every 15 minutes until the Cycolac chips are dissolved. Preparation time is approximately two hours. **CAUTION:** Stir thoroughly at each interval or the Cycolac will solidify. Cover the container when not mixing. For best results, the Cycolac should have a putty-type texture. Add acetone to thin, as necessary. Makes approximately 6 oz. of liquid Cycolac.

Clean the surface with acetone before applying Cycolac.

Store unused portion in a sealed glass or metal container. Limited shelf life once mixed.