K00162 AIR BAFFLE KIT

Installation Instructions

1. Remove front panel and top cover.
2. Remove the screw that holds on louvered portion of side panel.
3. Remove double sided tape backing from enclosed baffle, and place baffle on the side panel, making sure the slot at the top of the baffle aligns with hole in side panel. Attach baffle and side panel with original screw to cornerpost angle.
4. Remove existing screws that attach back panel to cornerpost. Install air baffle to cornerpost and attach with original screws.
5. Install top cover and front panel.

Manitowoc Ice, Inc.
2110 South 26 Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879
8011553
07/02/98