MANITOWOC ICE
2110 SOUTH 26TH STREET, MANITOWOC, WI 54220

800-545-5720
WWW.MANITOWOCICE.COM

Instruction Sheet

Subject: K00455 LuminIce™ II Remote LED

INSTALLATION INSTRUCTIONS

Installation notes:

1. This kit is only compatible with Luminice™ II and will not function with the first generation of Lumince.™
2. 22″ & 30″ models allow the remote LED to be mounted on either the right or left side of the ice machine.
3. 48″ wide models only allow mounting on the right side of the ice machine .
4. The right side is always preferred to bring the light as far forward as possible.
5. When mounting on the left side the lights final position will be in the middle of the left panel. Do not mount the bracket forward as it will be positioned in the food zone.


Installation

Step 1 Disconnect power to the ice machine at the electrical disconnect.

Step 2 Place grommets in the bracket.




Step 3 Insert LED through the grommets.




Step 4 Remove top cover from ice machine.

Step 5 Hang bracket on side of ice machine in final position.



Step 6 Route wiring to LuminIce™ II.

Step 7 Connect LED wire to LuminIce™ II.



Step 8 Verify placement of the bracket/LED and reinstall the top cover on the ice machine.

Step 9 Restore power and test run.

Document Number: 000013458_01 5/21