MANITOWOC FOODSERVICE – ICE MACHINE DIVISION
2110 SOUTH 26TH STREET, MANITOWOC, WI 54220
800-545-5720
WWW.MANITOWOCICE.COM

Instruction Sheet

Subject: Gear Box Venting


Vent Cap Removal

The vent for the gear box is sealed with a cap to prevent oil leaks during shipping.

The cap must be removed from the vent before operating the gear motor assembly.

⚠Warning

Disconnect electric power to the ice machine (and dispenser if applicable) at the electric switch box before proceeding.



The yellow vent cap covers the vent and is removed by pulling upward. Discard cap after removal.



Vent is unrestricted after removal of the cap.