ADJUSTABLE CASTER LEGS

Installation Instructions

These casters may be used only on the following Manitowoc ice machine and storage bins: G-0150 ice machines, C-170 and C-400 storage bins. These casters may also be used on the following reach-in cabinets with screw-in mounting bases: AV1A, AV2A, and AV3A.

WARNING: CASTERS ARE NOT TO BE USED WHEN STACKING MACHINES OR IN CONJUNCTION WITH BIN SLEEVES.

1. Lay the bin on its side on a piece of cardboard while attaching the tubular leg assemblies to the bin bottom.
   NOTE:
   A. Do not lay ice machine on its side, as it could damage the refrigeration system. Tilt the G-0150 back to install and lock front casters and tilt forward to install rear casters.
   B. The casters must be attached to the reach-in cabinet before installing the refrigeration system.
2. Attach the casters to the tubular leg assemblies. The casters with brakes must be mounted on the front of the bin, ice machine, or reach-in cabinet.
3. Attach the set screws to the tubular leg assemblies, two in each leg.
4. After the casters are secured, stand equipment upright and place in intended location.
5. To level, loosen the set screws and turn casters clockwise to decrease height and counterclockwise to increase height. Each leg can be adjusted approximately one inch. After leveling, retighten all set screws.

CAUTION: Do not extend leg on caster beyond the maximum height adjustment indicated by the groove on each leg. Casters are for pulling the equipment away from the wall for cleaning and servicing and not for transporting ice machine or ice.