MANITOWOC ICE
2110 SOUTH 26TH STREET, MANITOWOC, WI 54220

800-545-5720
WWW.MANITOWOCICE.COM

Instruction Sheet

Subject: Swivel Caster

INSTALLATION INSTRUCTIONS

⚠Warning

Authorized Service Representatives are obligated to follow industry standard safety procedures, including, but not limited to, local/national regulations for disconnection / lock out / tag out procedures for all utilities including electric, gas, water and steam.

DANGER

Disconnect electric power to the ice machine at the electric switch box before proceeding. Failure to disconnect the power at the main power supply disconnect could result in serious injury or death. The power switch DOES NOT disconnect all incoming power.

⚠Warning

This equipment contains refrigerant charge. Procedures must be performed by a properly trained and certified refrigeration technician aware of the dangers of dealing with refrigerant charged equipment.

DANGER

These casters cannot be used on bins or when stacking two ice machines on a storage bin.

These casters are used on self contained undercounter ice machines only and are not to be used on bins.

1. These casters are non-leveling. The floor must be level for proper equipment operation.
2. Assemble thread bushings to casters.
3. Lift and support ice machine while attaching casters.
4. After all four casters are secured, remove support from ice machine and verify the ice machine is level.
5. K00064 caster kit - Lock the two casters when installation is complete.

Document Number: 8003393_03 5/19