7624973
G-0150 BIN DOOR TRIM REPLACEMENT KIT

1. Front Panel/Trim Removal

    A. Remove either bin door hinge, right or left-hand.
    B. Remove bin door.
    C. Remove six screws holding the front panel in place. Remove front panel. Save four front panel mounting screws.
    D. Remove three screws holding the stainless trim and remove stainless trim. Discard screws and trim.

2. Installation of Front Panel and Stainless Trim

    A. Position new stainless trim over holes and secure with three #8 x 1/2 Phillips sheet metal screws provided in this kit.
    B. Insert top edge of front panel under the offset flange of the stainless trim.
    C. Align the front panel holes with the four holes in the machine and secure with the four previously removed screws.
    D. Replace bin door and hinge.

