AIR-COOLED CONDENSER FILTER

Installation Instructions

Note: The condenser filter must be installed to prevent dust, lint, and grease form entering condenser fin area.

1. Clean the surfaces where the channels are to be located. The surface must be clean, dry, and free of oil or grease for good adhesion of mounting channels.

2. Install bottom channel, as shown. Use moderate pressure to insure good adhesion between tape and mounting surface.

3. Place filter in bottom channel, center air filter over condenser fin area, and mark location of side mounting channels, allowing clearance for filter to slide easily.

4. Install side mounting channels using moderate pressure to insure good adhesion between tape and mounting surface. Insert filter.

