S-SERIES INVENSYS WATER INLET

Installation Instructions

This valve is not rebuildable - replace the entire valve only. Do not use components from a new valve to rebuild an existing valve.

1. Disconnect power to ice machine.
2. Turn off water supply to ice machine.
3. Remove front cover, top panel, and right side panel.
4. Unplug wire leads from water inlet valve coil, pull back insulation, and disconnect water inlet tube from water inlet valve.
5. Remove the two #10 screws from the water inlet valve.
6. Install the new water inlet valve using two #10 screws.
7. Reconnect the water inlet tube to the water inlet valve.
8. Reconnect wire leads to the water inlet valve coil.
9. Install side panel, top panel, and front cover.

Manitowoc Ice, Inc.
2110 South 26th Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879
Web Site - www.manitowocice.com

8016583
01/06/05

