B-SERIES SINGLE EVAPORATOR
REMOTE 1 PHASE

CAUTION: DISCONNECT POWER BEFORE WORKING ON ELECTRICAL CIRCUITRY.

DIAGRAM SHOWN DURING FREEZE CYCLE.




Figure 6-15.