
UNF0300/RFF0320/UFF0350/UNF0350/RFF0620



Compressor Wiring Legend	
50	Compressor
51	Run Capacitor
52	Start Capacitor
53	Relay
54	Overload